

## วิธีการ upgrade receiver Wave com

Download file loader ( Arioner\_024 )

Download file S192CNCL\_\$WVL\_E6579\_20050927\_AUCPCnpc.zip autodream


Click open file loader

Select Com port 1 , 2


Click file to send OPEN Select file S192CNCL\_\$WVL\_E6579\_20050927\_AUCPCnpc.

Click Send program to ird


On power Receiver wave com




Click open select file




Click open select file S192CNCL\_\$WVL\_E6579\_20050927\_AUCPCnpc




Click Send program to ird and on power Receiver Wave com



Send program to ird 100 %



**Please Waiting terminate request    look at No : in    Retry**



Download successfully.

WWW.SatTHAI.NET